

## BACKDROP FRAME PARTS AND INSTALL



**NEED: PHILLIPS SCREWDRIVER, 2 PEOPLE, 10-15 MINUTES**

- 1. LAYOUT PRINT FLAT ON GROUND WITH PRINTING FACE UP**
- 2. ASSEMBLE FULL FRAME ON TOP OF PRINT**
- 3. SLIDE SIDE POLES INTO POCKETS**
- 4. SLIDE TOP AND BOTTOM POLES INTO POCKETS AND CONNECT HAND SCREWS**
- 5. HAVE HELPER TIGHTEN THE OPPOSITE TIGHTEN POINT AND HOLD THE END OF THE PRINT AND POLE WHILE SECOND PERSON GENTLY PULLS TO CORRECT TENSION AND THEN TIGHTENS POLE ON OTHER SIDE AND TIGHTEN POINT (REPEAT ALL 4 POLES)**
- 6. ATTACH FEET**
- 7. WITH 1 PERSON ON EACH SIDE LIFT BACKDROP INTO POSITION**
- 8. USING TIGHTEN POINTS LOOSEN AND CORRECT TENSION, THEN RETIGHTEN (TAKES SOME ADJUSTMENT)**