INSALLING STAND OFF MOUNTS





1. LEVEL PANEL



2. MARK HOLES



3. SCREW SPACERS INTO WALL



4. HOLD PANEL & ATTACH CAPS



EXTRA HEAVY PANEL?

BEFORE SCREWING CAPS

DRILL HOLES & INSERT ACHORS

